



## Prior to Install

- Thoroughly read the enclosed installation instructions.
- Install only under permanent lighting conditions.
- Versa Impact and the area to receive the product must be maintained between 65°-80°F at 50% or less for at least six days prior to and after installation.



## Preparing the Walls

- Remove any old wallcovering materials – NEVER DOUBLE HANG.
- All surfaces to receive vinyl wallcovering must be smooth, clean, dry and structurally sound. Glossy areas should be sanded and rough irregularities repaired.
- To promote adhesion all new walls should be primed with a suitable non-oil-based primer and allowed to dry according to the manufacturer's recommendation.
- A layer of commercial grade wallcovering adhesive should be applied via a roller to the wall and allowed to dry to the touch. This drying step should take approximately one hour and will provide "initial tack" necessary to successfully adhere the Wall Protection product to the wall.
- A light sanding of the pre-pasted wall surface may be required prior to applying the Versa Impact product.



## Prepping the Versa Impact Product

- Rolls must be cut and installed in sequence, starting with the lowest numbered roll.
- Measure wall and a prepare plumb line to ensure a straight hang.
- Mark and pre-cut strips according to wall dimensions. Seams may be pre-cut or overlapped and double cut on wall.
- Only heavy-duty strippable clay based commercial grade wallcovering adhesive should be used.
- Apply a liberal amount of adhesive to the back of the wallcovering with a paint roller and allow to book for a minimum of 15 minutes.



## Installation

- Care should be taken when handling the material to avoid the creation of creases.
- Install each sheet using a stiff flexible plastic broad-knife.
- Inside corners can be made by cutting and joining in the corner.
- Outside corners will not wrap and will need to be made by trimming the material to the outside corner of the adjoining walls and finished with a cap molding.
- Seams on non-matched patterns may be table trimmed, or overlapped and double-cut during installation, exercising care not to cut too deeply into the wall substrate. A double cutting tool specifically designed to prevent cutting into the wall when cutting the seams is commonly available and is recommended.
- Due to the heavy-duty construction of the product it is highly recommended that the razor blade be changed frequently in order to ensure clean cuts.
- When "railing" begin in the middle of the section and work your way out to the ends.
- Remove excess adhesive and dirt from wallcovering surface, seams and surrounding surfaces immediately, using a natural sponge or damp cloth frequently rinsed in clean, warm water and dry with a soft, lint-free cloth.